



Water Mat Weatherproof storage bag Closing Instructions

1. Insert the water mat into the bag, align the top edges of the bag and squeeze them together
2. Tightly roll down the top of the bag at least 3 times (it is better to roll it down all the way until you reach the water mat - this puts more tension on the closure and makes the seal better)
3. Clip the two middle buckles together
4. Bend the ends in the opposite direction towards the back, away from the side where you rolled the top down (again this puts more tension on the fold and makes a better seal).
5. Buckle the ends together and you are done.

