



www.crocpad.com

Crocpad Water Mat User Manual





TABLE OF CONTENTS

Included in the package.....	2
How to add or replace a new anchor point.....	3
How to connect the bungee tether leash.....	4
Crocpad water mats.....	5
Accessories.....	6
Using your Crocpad.....	7
Care and maintenance.....	8
Warranty.....	8

Included in the package


- ✓ 1 x Crocpad water mat
- ✓ 2 x pre-installed anchor kits
- ✓ 2 x 3m bungee cords
- ✓ 2 x Velcro straps





How to add or replace a new anchor point

- ✓ Use a drill with a 48mm hole saw
- ✓ Drill a hole in a piece of timber and use it as a pilot hole
- ✓ Place the piece of timber with pilot hole with on the mat where you need to make the hole - at least 400mm away from the edge
- ✓ Use the hole saw to drill carefully until you go completely through to the other side.
- ✓ Now you have the hole ready, insert the spacer into the anchor point as shown in picture 2
- ✓ Insert the anchor point with the spacer into the hole.
- ✓ Now turn the mat and insert the second part of the anchor point into the hole as shown in picture 3
- ✓ Insert the screws and lock as shown in picture 4






How to connect the bungee tether leash

- ✓ Remove the black grommet (anchor sphere) from the bungee cord
- ✓ Feed the bungee cord through the anchor on the mat (Pic 5)
- ✓ Feed the bungee cord through the anchoring sphere (Pic 6)
- ✓ Create a knot with the bungee cord (Pic 7)
- ✓ Pull the cord back and fix the anchor sphere in the grommet (Pic 8)
- ✓ All done, you can now secure the Crocpad mat to your boat or pole.


TETHER ASSEMBLY INSTRUCTIONS



1



2



3



4



5




6



7



8



9



Crocpad water mats

The Crocpad water mats come in three different sizes while they share the same design and strength.

- ✓ 3 x layer marine grade XPE foam
- ✓ 2 x layer tear stop Nylon matrix
- ✓ 2 x Velcro strap

550cm x 180cm	650kg capacity	8-10 adults	2 anchor kits
360cm x 180cm	500kg capacity	5-6 adults	2 anchor kits
200cm x 100cm	120kg capacity	1 adult/ 2 kids	1 anchor kit

Junior – 2m

Dimensions : 200cm x 100cm x 3.3cm

Weight : 3kg

1 x Anchor point pre-installed

1 x 12ft bungee cord

Senior – 3.6m

Dimensions : 360cm x 180cm x 3.3cm

Weight : 10kg

2 x Anchor points pre-installed

2 x 12ft bungee cord


Jumbo – 5.5m

Dimensions : 550cm x 180cm x 3.3cm

Weight : 14kg

2 x Anchor points pre-installed

2 x 12ft bungee cord





Accessories

The Crocpad water mat comes with anchor kits and Velcro straps. Additional anchor kits and Velcro straps can be ordered online.

Crocpad offers a waterproof and UV resistant high quality storage bag which can also be ordered separately online.

ANCHOR KIT



VELCRO STRAPS



STORAGE BAG





Using your Crocpad



This product is to be used for noncommercial water recreation with proper adult supervision. This is not intended as a flotation device. It is recommended that all users wear a suitable life jacket or personal flotation device (PFD) before entering the water. Users of this product assume any and all risks of injury. The safest location for use of your Crocpad is in sufficiently deep water, away from boat traffic and clear of obstructions, such as piers, docks, rocks and sandbars, etc. After you find the ideal location to place your Crocpad, attach the leash directly to an anchor or mooring point to keep it from drifting away. If you plan to leave it in the water for an extended period of time during the day, you should attach a buoy or marking flag. It is not intended for use on land or in swimming pools.

Your Crocpad is not a toy that is designed to be pulled or towed behind a boat or personal watercraft and as such does not have any braking or steering devices. Towing it is dangerous and could cause damage to the foam mat and people.

- Common sense should dictate the number of persons allowed on the Crocpad at one time.
- Never allow a child to use the Crocpad without supervision.
- The Crocpad is not a lifesaving device.
- Do not leave children unattended while in use.
- Use only under competent adult supervision.
- Only to be used in water in which the child is within its depth and under adult supervision.
- Do not swim or play under the Crocpad and do not dive from the Crocpad.
- Do not jump from other objects onto the Crocpad.
- Never use the Crocpad if you are under the influence of alcohol or drugs.
- Do not attempt to swim from the mat to another object or the shore if you are fatigued.
- Never use the Crocpad during storms where lightning is present, before sunrise, or after dark.
- It is not invincible, so please keep the Crocpad away from sharp objects, stumps or edges.
- Inspect the Crocpad, tethers, cords and anchors for wear or defects before every use. If the mat is anchored, precautions should be taken to eliminate activities that could cause entanglement in the tether leash or anchor rope.





Care and maintenance

The Crocpad is made from cross-linked polyethylene foam and does not require any other floatation device or air, so set up and maintenance is simple.

Use a sponge to wipe off any foreign material or debris that could scuff or damage the surface. UV rays are damaging to the surface and could cause fading and hazing of the surface if left in sunlight for weeks at a time. To prolong the life and appearance of your Crocpad, keep it dry and protected from sunlight and the elements when not in use.

Warranty

Your Crocpad comes with a one year warranty as set forth below and is given by Crocpad.com.

In respect to products purchased and used in Australia. Crocpad products, when delivered to you in a new condition in the original box, are warranted against defects in material or workmanship for one year from date of purchase so long as the product remains in the possession of the original owner. Defective product(s) returned to Crocpad.com and proven to be defective upon inspection, will be repaired or exchanged for a new product where applicable.

The warranty period for any replacement product shall be consistent with the terms set forth in the original One Year Warranty. When returning any product under this One Year Warranty, you must first contact us to obtain return authorization. The product must be packaged securely with a copy of the invoice or bill of sale, together with a complete description of the defect. Shipping charges, if any, will be prepaid by the customer. Products covered by this One Year Warranty will be returned to you without charge by Crocpad.com .



The One Year Warranty covers only manufacturing defects and does not apply in the following cases:

- Loss or damage to the product due to abuse; mishandling; alteration; accident; failure to follow maintenance or storage instructions; or any acts of God, including storm or animal damage.
- Loss or damage to the product from towing or incorrect tethering.
- Surface snags, scuffs & tears from sharp objects, including metal objects, nails, claws, swimsuit ornamentation, jewellery, other water toys, etc.
- Wear and tear from normal use and weathering, including weathering from UV light. This One Year Warranty shall not extend to anyone other than the original purchaser of the product. No implied warranty, INCLUDING THE IMPLIED WARRANTY OF MERCHANTABILITY, or fitness for a particular purpose, applies to the product after the applicable period of express warranty stated above. No other express warranty, except as mentioned above, given by any person, firm, dealer or corporation with respect to your Crocpad shall bind Crocpad.com.

Crocpad.com will not be liable for loss of revenue or profit, failure to realize savings or other benefits, or for any other special, incidental or consequential damages caused by the use, misuse or inability to use the product regardless of the legal theory on which the claim is based, and even if Crocpad.com, has been advised of the possibility of such damages.

Nor shall recovery of any kind against Crocpad.com be greater in amount than the purchase price of the product sold by Crocpad.com. Without limiting the foregoing, you and any user of your Crocpad, assumes any and all risks and liability for loss, damage or injury to you, your property, and to others and their property arising out of the use, misuse, or inability to use any product sold by Crocpad.com, not caused directly by the negligence of Crocpad.com.

This One Year Warranty gives you specific legal rights, and you may have other rights which may vary by state. Should you have any questions, please contact us via our website www.crocpad.com.